

Fuji D-6 Shifter

- A. Run full shifter housing through frame.
- B. Rear derailleur cable housing will exit frame directly to rear derailleur.



A.



B.

- C. Front derailleur housing will stop inside frame and bare cable will exit directly to front derailleur.
- D. In-line barrel adjusters are strongly recommended!
- E. Adjust derailleurs as normal.



C.



D.